

## Fitting an MGF / TF Screen !!!

### Removing / Re-Fitting instructions:

1. From the inside of the car, pull back carpet and un-clip clips to release frame. (watch your fingers!! )
2. From outside of the car, pull up bow, use a chisel / flat screwdriver and hammer to knock heads of rivets, remove metal strip that holds the bottom of the window section.
3. From the inside of the car, tear of metal ring attached to zip end, un-zip and remove window section from the car.
4. Remove rivets to clear the holes on the bow, using a hammer and punch,( nail / pop rivet ) Or drill out.
5. Place new window section on roof of the car, lift bow vertical and use rivets provided to rivet back onto frame and also re-using the metal strip.
6. Once riveted..Lower the bow, Then from the inside of the car, zip in the new window section. Re-clip the bow. Check Velcro is sitting correctly.